

# How to Use the Map View

The map gives a view of your entire fleet across a region. In addition, the colour indicates the status of each vehicle.

To view the Map View, select Map View from the left-hand menu.



You can Search for a specific vehicle by selecting the Arrow to bring out the entire list of your fleet.



If you click on a vehicle from the map view you will see a mini dashboard of that vehicle.

## IRE HEAD OFFICE

Unit 20A Beckett Way, Parkwest Business Park, Dublin 12, Ireland. D12 P8R2 Tel: +353 (0)1 963 1380

#### REGIONAL OFFICE

Arclabs Research & Innovation Centre WIT West Campus, Carriganore, Co. Waterford Tel: +353 (0)1 963 1380

#### UK HEAD OFFICE

Unit F3, LEFA Business Park., Sidcup, London United Kingdom DA14 5BH Tel: +44 (0)20 3740 3562

### My Safe Drive Ltd t/a CameraMatics


Registered in Ireland No. 548843 Directors: M. O'Callaghan, S. Murray, G. Burchell (GB), J. Wyles (GB)

# Provision Vehicle Camera Limited t/a CameraMatics

Registered in England No. 09939849 Directors: M. O'Callaghan, S. Murray, S. Warne

CAMERAMATICS.COM





This dashboard shows live data coming from the vehicle. It also includes live widgets as follows:

- Vehicle Detail This will have more details on the vehicle
- **Driving Events** This will show any driving events that the vehicle has occurred during a specific time frame
- Faults This will show any faults with the CameraMatics system installed
- Live Streaming This will show the live streaming from the cameras on the vehicle
- Retrieve Media This will allow you to pull footage from a date and time you want
- Tracking This will show you a variety of tracking reports for this vehicle

**CAMERAMATICS.COM**