


How to View Geofence Events


As your fleet is completing trips, they will trigger events relating to any geofences you have created. You can view these events in more detail by using the Geofence Events feature.

Click Geofence Events from the left-hand menu.



This displays a full list of all the geofence events that have taken place within the time frame you have selected.

If you click on one of these events, you will be shown where the event has taken place on a map. In the top right, you can click to view the tracking specific to this event, or retrieve the footage for this event if the vehicle is not in an offline status.



IRE HEAD OFFICE

Unit 20A Beckett Way, Parkwest Business Park, Dublin 12, Ireland. D12 P8R2 Tel: +353 (0)1 963 1380

REGIONAL OFFICE

Arclabs Research & Innovation Centre WIT West Campus, Carriganore, Co. Waterford Tel: +353 (0)1 963 1380

UK HEAD OFFICE

Unit F3, LEFA Business Park., Sidcup, London United Kingdom DA14 5BH Tel: +44 (0)20 3740 3562

My Safe Drive Ltd t/a CameraMatics

Registered in Ireland No. 548843 Directors: M. O'Callaghan, S. Murray, G. Burchell (GB), J. Wyles (GB)

Provision Vehicle Camera Limited t/a CameraMatics

Registered in England No. 09939849 Directors: M. O'Callaghan, S. Murray, S. Warne

CAMERAMATICS.COM



You can also adjust the filter for these events if you want to view a specific type of event, such as grouping the events by vehicle rather than geofence.

