How to set up live alerts

1. Click on Vehicles:


2. Click the three dots in the right column:

3. Click on Alert Config:

4. The Alert Settings will then open:

5. Click the drop down Accelerometer alerts menu to configure alerts for G-force, AI alerts and panic button alerts. Select which camera lenses that you want video:

Alert Settings

Accelerometer Alerts ▾

Enable Alerts
Upload Alert Footage
Select Cameras: ☑ Use all available cameras

☑ Driver
☑ Forward

SUBMIT

6. Click configure multiple:

Alert Email Settings

Potential Collision ▾   CONFIGURE MULTIPLE

Recipients 👤   Send to Self ☐

7. Click to select the items you want included in the alerts

Configure Multiple Alert Email Lists ✕

Dynamics	ADAS	Driver Monitoring	Inputs
☑ Potential Collision	☐ Pedestrian Collision	☑ Phone	☑ Driver
☑ Harsh Braking	☐ Lane Departure	☐ Fatigue	
☐ Harsh Steering	☐ Forward Collision	☑ Distraction	
		☐ Smoking	

8. Click on Recipients you want to receive the alerts, also click send to self if you want them and then click SUBMIT

☑ Harsh Braking	☐ Lane Departure	☐ Fatigue	
☐ Harsh Steering	☐ Forward Collision	☑ Distraction	
		☐ Smoking	

Recipients 👤   Send to Self ☐

SUBMIT